



# Installing a Core Drill Post

## Core Drill Mounting Steps

1. Make a 6 1/4" deep by 3" diameter hole in your concrete
2. Mount your post 6" into the hole you just made, leaving 1/4" for minor adjustments
3. Back fill the hole with concrete, once you've positioned your post
4. Place the foot cover down over the post
5. Repeat steps 1-4, then proceed to handrail mounting instructions

## Core Drill Post Information

- Useful for creating railing on concrete
- Bottom of post buried in concrete
- Post will be roughly 6" longer than handrail height

